WF-SL*KIT

WarmFlo® Select Conversion Kit

WF-SL*KIT

1 = SL1, single stage HP or 1 or 2-stage A/C
2 = SL2, two stage HP

 $\mathbf{C} = \mathbf{SLC}$, Bryant EvolutionTM or Carrier InfinityTM

Bryant Evolution[™] control –
SYSTXBBUID01-B
Heat Pump – 286ANA, 265ANA,
263ANA

Gas Furnace – 355CAV

Carrier Infinity $^{\text{TM}}$ control system – SYSTXCCU***

 $Heat\ Pump-25HNA6,\ 25HPA5,$

25HPA3

Gas Furnace – 58MVC

Application

These kits are designed to convert an existing WarmFlo Select plenum heater to another version of WarmFlo Select plenum. These kits are **not** designed to convert a WarmFlo II or standard plenum heater to a WarmFlo Select.



02/05/2009 EI713

WF-SL*KIT Installation Steps



DISCONNECT ALL ELECTRICAL POWER BEFORE ELECTRICALLY CONNECTING OR SERVICING THE UNIT. FAILURE TO DISCONNECT THE ELECTRICAL POWER BEFORE WORKING ON THIS PRODUCT CAN CREATE A HAZARD LEADING TO PERSONAL INJURY OR DEATH.

Installation

Step 1

Disconnect all wiring from the existing control board.

Step 2

Remove the existing door that the control board is fastened to by removing three screws located on the right hand side of the cabinet.

Step 3

Install the new door and control board assembly.

Step 4

Reconnect the factory wire harness, temperature sensors, field wiring, etc.

Electrical Installation Overview

For detailed field wiring information and setup and operating procedures, please reference the attached installation manual. The installation manual included with this kit replaces the original manual sent with the plenum heater as it was shipped from the factory. Please discard the old installation manual and replace with this new one.